




## **FTTM-8 INSTALLATION INSTRUCTIONS**


For more instructions, please visit orcahardware.com.





Ø8(x2)







Ø8(x4)


M6x40 (x 4)

Ø8 (5/16")

Ø5.5 (3/16







For more instructions, please visit orcahardware.com.

Version FTTM-8 1-1